



Kohler Engine Maintenance Schedule

Frequency	Maintenance Required
Daily or before starting engine	<ul style="list-style-type: none"> -Fill Fuel tank -Check oil level -Check air cleaner for dirty, loose or damaged parts. -Check air intake and cooling areas, clean as necessary.
Every 25 hours	<ul style="list-style-type: none"> -Service precleaner element
Every 100 hours	<ul style="list-style-type: none"> -Replace air cleaner element -Change oil (more frequently under sever conditions) -Remove cooling shrouds and clean cooling areas. -Check oil cooler fins, clean as necessary (if equipped)
Every 200 hours	<ul style="list-style-type: none"> -Change oil filter -Check spark plug condition and gap -Replace fuel filter (carbureted engines)
Every 250 hours	<ul style="list-style-type: none"> -Replace heavy-duty air cleaner element and check inner element
Annually or every 500 hours	<ul style="list-style-type: none"> -Have bendix starter drive serviced -Have solenoid shift starter disassembled and cleaned
Every 1500 hours	<ul style="list-style-type: none"> -Replace fuel filter (EFI engines)